


## ET Holder



Unit:mm

Size No.	Applicable Size of E-Ring			ET Holder Size No.	Dimension				
	Diameter of inner periphery	Diameter of outer periphery	Plate thickness		L	F <sub>1</sub>	E	G	H
ETW- 0.6	0.6	1.5	0.2	ETH- 0.6	123	39	3.6	12	5
0.7	0.67	2	0.2	0.7, 0.8			5		
0.8	0.8	2	0.2	0.7, 0.8					
1	0.98	2.8	0.2	1	122	38	7	9	8
1.2	1.2	3	0.3	1.2					
1.5	1.5	4	0.4	1.5					
1.9	1.9	4.5	0.4	1.9	124	40	10	10	8
2	2	5	0.4	2					
2.3	2.3	6	0.4	2.3, 2.5					
2.5	2.5	6	0.4	2.3, 2.5	123	43	12	12	8
3	3	7	0.6	3, 3.2					
3.2	3.2	7	0.6	3, 3.2					
4	4	9	0.6	4	129	49	18	16	10
5	5	11	0.6	5					
6	6	12	0.8	6					
7	7	14	0.8	7	154	54	21	18	12
8	8	16	0.8	8					
9	9	18	0.8	9					
10	10	20	1	10	160	60	24	20	14
12	12	23	1	12					
							163		
					165	65	29	26	