


Calculations for Compressed Spring Washers (Reference)

1 Load and Stress Calculations of Wave Washer

Fig. 1 Wave Washer



Load

$$P = \frac{16Ebt^3N^4\delta}{\pi^3 D_m^3} \quad (1)$$

Stress

$$S = \frac{0.75\pi P D_m}{bt^2 N^2} \quad (2)$$

- P:** Load (N)
- S:** Stress (N/mm²)
- D:** Diameter of outer periphery (mm)
- d:** Diameter of inner periphery (mm)
- D_m:** Average diameter (mm) [= (D + d)/2]
- b:** Rim width (mm) [= (D - d)/2]
- t:** Plate thickness (mm)
- N:** Wave number
- δ:** Amount of deflection (mm)
- E:** Longitudinal elastic modulus (N/mm²) (Table 1)
- π:** Circumference ratio

Table 1 Longitudinal elastic modulus of main materials (E)

Material	Longitudinal elastic modulus (N/mm ²)
Carbon spring steel	206000
Stainless steel for spring	181000

Reference for design

To change the load by a large amount | Please adjust the plate thickness and wave number. The load is proportional to the cube when adjusting the plate thickness, and to the fourth power when adjusting the wave number. (However, as the number of waves increases, it becomes easier to settle, so please consider the basic three waves.)

To change the load by a small amount | Adjust the diameters of inner and outer peripheries (rim width). The load is proportional to the rim width.

Notes

There are differences between the calculated and measured values for the formula of deflection and load. Substitution of conditions such as diameters of outer and inner peripheries gives a first-order equation of deflection and load which is plotted as a straight line. However, the actual load curve will not be a simple straight line but a curve.